



Global Water Instrumentation Inc.

WL15 Water Level Logger: Battery Guidelines

- This is a 9 VDC, Lithium battery powered device.
- Please remember that anytime the computer or PDA is connected to the logger, the battery will drain more rapidly than under normal conditions.

Keep this in mind if you do the following actions:

1. Read sample continuously for more than 30 seconds.
 2. Saving logger data to a file.
 3. Set sample time interval to 15 minutes or less in setup.
- When saving data to a file, verify that the number of retrieved data readings match the number of readings in history.
 - If the retrieved number of data readings do not match the number saved to your file, install a new battery and retry.
 - For your convenience the Ultra life batteries website is: <http://www.UltralifeBatteries.com>. Click on Non-rechargeable Batteries.

- Note:**
1. You may use alkaline batteries in an emergency
However, switch back to lithium as soon as possible.
 2. Changing batteries does not cause data or setup parameters to be lost or modified.