

# BLR-Series Disposable Bailers

Polyethylene Bailer for Groundwater Sampling



## Description

The BLR-Series single use disposable bailers help eliminate the common storage and cross contamination problems associated with conventional bailers. The BLR's design allows the bailers to fill 33% faster than conventional units. The bailers feature a V-notch top for easy cord attachment and pouring, a retained check ball valve for easier sampling, and welded seams for extra strength. The BLR units are certified clean through independent laboratory testing and analysis on each material lot. Weighted bailers have a completely encapsulated weight so no metal comes in contact with the sample. The double check valve bailer isolates the sample, sealing it as the bailer is removed from the well at specific depths.

## Pressurized Disposable Bailers

The special pressurized bailer provides the convenience of using inline dispos-a-filters™ in the field even when pumps are not available. By using a pneumatic hand pump, you can filter your samples directly from the disposable bailer, saving time while maintaining sample integrity. Pressurized bailers come complete with barbed hose adapters for attaching the hand pump to the top of the bailer, as well as special adapters with a notched thread to be used with a dispos-a-filter™ at the bottom. In order to displace the check ball and establish a smooth flow, an additional large barbed removal device is included for bottom emptying without filtering.

## Features

- Fills 33% faster than other bailers
- Trouble-free cord attachment and accurate pouring
- Manufactured under strict clean room conditions
- Highest quality, virgin materials

## Ordering & Options

### Disposable Bailers

| Order No. | Diameter | Length | Configuration | Units/Case |
|-----------|----------|--------|---------------|------------|
| CVA000    | 3/4"     | 36"    | Non-Weighted  | 24         |
| CVA010    | 1-1/2"   | 12"    | Non-Weighted  | 24         |
| CVA020    | 1-1/2"   | 36"    | Non-Weighted  | 24         |
| CVA030    | 1-1/2"   | 48"    | Non-Weighted  | 24         |
| CVB000    | 3/4"     | 36"    | Weighted      | 24         |
| CVB010    | 1-1/2"   | 12"    | Weighted      | 24         |
| CVB020    | 1-1/2"   | 36"    | Weighted      | 24         |
| CVB030    | 1-1/2"   | 48"    | Weighted      | 24         |
| CVB040    | 1-1/2"   | 83"    | Weighted      | 12         |
| CVB050    | 3"       | 36"    | Weighted      | 9          |
| CVC000    | 1-1/2"   | 36"    | Double Check  | 24         |
| CVD000    | 1-1/2"   | 36"    | Pressurized   | 12         |

### Accessories

| Order No. | Description                                      | Units/Case    |
|-----------|--|---------------|
| CVEA00    | Poly VOC Tips for 3/4" Diameter Bailers          | 24            |
| CVEA10    | Poly VOC Tips for 1-1/2" Diameter Bailers        | 24            |
| CVEA20    | Poly VOC Tips for 3" Diameter Bailers            | 9             |
| CVEB00    | Product Samplers (for free product sampling)     | 24            |
| CVEC00    | Suspension Cable, White Nylon 1/8" Diamond-Braid | 1,000 ft/roll |
| CVEC10    | Suspension Cable, Yellow Nylon 3/16" Std. Braid  | 1,000 ft/roll |
| CVEC20    | Suspension Cable, Nylon, #15                     | 350 ft/roll   |
| CVED00    | Hand Pump for Pressurized Bailer                 | Each          |



In the U.S. call toll free  
at 1-800-876-1172  
International: 1-979-690-5560  
Fax: 1-979-690-0440  
Email: [globalw@globalw.com](mailto:globalw@globalw.com)

Visit our online catalog at:  
[www.globalw.com](http://www.globalw.com)  
Our Address:  
11390 Amalgam Way  
Gold River, CA 95670